



## GM Anti-Drag® Steel Plates Racing Aluminum Powerglide®

### ALTO PART # 019711KUP1

Powerglide Alum Front Kolene® w/6 Separators

### ALTO PART # 019713KUP1

Powerglide Alum Reverse Kolene® w/6 Separators

## INSTALLATION INSTRUCTIONS

Stack-up is the same as OE, with alternating friction and steel plates. To insure correct clutch pack clearance when using the Anti-Drag® Steel Separators, first assemble the clutch packing using conventional steel plates of the same thickness as the Anti-Drag® Steel Plates. Apply the clutch several times and then measure clutch pack clearance. After making adjustments to the correct clutch pack clearance, assemble the clutch pack using the Anti-Drag® plates. Position the Anti-Drag® Steel Plates so the viton spacers give each friction plate clearance.

