

Instruction Sheet No. 156
(Use in kit P/N 352800)

READ INSTRUCTIONS CAREFULLY. REMEMBER CLEANLINESS IS IMPORTANT.

SEAL P/N 352401 AND WIPER P/N 352404 INSTALLATION

- 1 Press seal 352401, "*spring side first*" into disconnect housing until seated in bore. See Figure 1.
- 2 Press wiper 352404, "lip side out" into bore against seal 352401. See figure 1.

Seal 352401: Apply light coat of Hi Temp Grease (MIL-G-3545A or Equivalent) Prior to Installation

